






KOALA


L I V I N G

Assembly Instruction







Product Name: Alessia Dual Electric Recliner Lounge - Right

Hardware List

- A  Washer Ø8*Ø17mm 24 pcs
- B  Allen Bolt M8*35mm 24 pcs
- C  Allen Key 6mm 1 pc
- D  Allen Bolt M8*35mm 3 pcs
- E  Allen Key 5mm 1 pc




Parts List




Note

1. Please check that all required hardware for assembly, as listed in the instructions, is available before beginning assembly.
2. For safety and efficiency, it's best to have two or more people assist with assembly to handle heavy parts safely and collaborate effectively.
3. Do not discard any packaging materials until assembly is complete.
4. Before assembling the item, carefully read all provided instructions.
5. Handle tools with care during assembly to prevent injuries.


1




2





3




4



5



6



7

