

KOALA


L I V I N G

Assembly Instruction


Product Name: Terzetto Console Table

Hardware List

A		Washer (B) Ø19mm	12 pcs
B		Spring Washer(B) Ø13mm	12 pcs
C		Allen Bolt (B) M8x35mm	12 pcs
D		Allen Key 5mm	1 pc
E		L Bracket 38x30x30mm	1 pc
F		Screw (B) M6x3x14mm	2 pcs
G		Wall Anchor Ø7x30mm	2 pcs
H		Screw (B) M8x4x35mm	2 pcs



Parts List



Leg
2 pcs






Table Top
1 pc




Note

1. Please check that all required hardware for assembly, as listed in the instructions, is available before beginning assembly.
2. For safety and efficiency, it's best to have two or more people assist with assembly to handle heavy parts safely and collaborate effectively.
3. Do not discard any packaging materials until assembly is complete.
4. Before assembling the item, carefully read all provided instructions.
5. Handle tools with care during assembly to prevent injuries.
6. A drill may be used, but only on a LOW setting to avoid damage.


1




2



3



4



Ensure all adjustable stoppers are firmly on the ground for stability

⚠ Warning

- ALWAYS secure this furniture with an anchor device
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves
- ALWAYS secure your television with an anchor device

