

KOALA

L I V I N G

Assembly Instruction

Product Name: Cassy Polished Gold Table Lamp
Cassy Brushed Graphite Table Lamp

Hardware List




E27 Bulb—1Pcs
Not included



Hex Key—1Pcs
(M4)



Set Screw—6Pcs




Parts List



Shade—1Pcs



Finial—1Pcs



Finial

Shade



Harp

Bulb
Not included



Socket

Saddle

Glass Rod


Lamp Body

Lamp Base


Set Screw



Harp—1Pcs



Eva Pad—6Pcs




Glass Rod—6Pcs

Lamp Body—1Set

Note


1. Assemble the item on a soft, well-lit surface, such as cardboard or carpet.
2. Follow the assembly procedure using the provided illustrations.
3. Do not discard any packaging materials until assembly is complete.
4. Handle electrical wires and tools carefully to avoid damage or injury.
5. Before assembling the item, carefully read all provided instructions and check all parts and components.

1




1. Retract the harp and then insert it into the slot of the saddle. Screw the bulb into socket (bulb not included).

2




2. Place the Eva pad on the bottom of glass rod. Insert the glass rod into the lamp body. Use wrench to lock the screws to the metal column to make the glass secure.

3



3. Place shade onto harp, screw finial onto the harp. When you install the shade is found to be tilted, you can adjust the shade in the opposite direction until it is parallel to the desktop.

4



4. Installation completed.

Important Safety Instruction

This is a portable luminaire. Before installing or removing the bulb, please turn off the power. Do not allow children to touch the lamp holder or bulb. Bulbs that have been on for a long time will be hot to the touch; please do not touch them.

220-240V a.c., 50Hz E27; Max. 40W ta: 25°C

If the external flexible cable or cord this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.

